


FERRULE FOR 1ST / R1A - 05100

Code	Tube		Dimensions	
	Hose Diameter		D mm	L mm
	Inch	mm		
05100-03	3/16"	4.8	17	26.5
05100-04	1/4"	6.4	20	29.5
05100-05	5/16"	7.9	22	29.5
05100-06	3/8"	9.5	24	32
05100-08	1/2"	12.8	29	34
05100-10	5/8"	16	32	37
05100-12	3/4"	19	36	43
05100-16	1"	25.4	43	50
05100-20	1-1/4"	31.8	52	57
05100-24	1-1/2"	38.1	57	63
05100-32	2"	50.8	70	78



FERRULE FOR 2ST / R2A - 05200

Code	Tube		Dimensions	
	Hose Diameter		D mm	L mm
	Inch	mm		
05200-03	3/16"	4.8	20	27
05200-04	1/4"	6.4	22	30
05200-05	5/16"	7.9	24	30
05200-06	3/8"	9.5	26	32
05200-08	1/2"	12.8	30	34
05200-10	5/8"	16	34	37
05200-12	3/4"	19	38	43
05200-16	1"	25.4	46	50
05200-20	1-1/4"	31.8	56	59
05200-24	1-1/2"	38.1	62	63
05200-32	2"	50.8	75	79

